

1. Packing List

5

1. Prestigio MultiPhone USB Cable

2. AC Adapter

Quick Start Guide 8. Battery

3. Earphone 9. Pouch

6. Warranty Card

7. Legal and Safety Notices 2. Device Overview

Vol +\ Vol - Button 2 **Earphone Jack**

Adjust the volume level Earphones connection.

3 **USB** port Micro USB cable connection.

Menu Display menu options.

Back Back to the previous page.

Home Back to the Home screen. Turn on/off the device: Power


Suspend/Activate the device.

Camera Take photos. 8

Speaker Listen to phone calls or music.

3. Uninstalling the back cover and battery

 Uninstalling the back cover: hold the side of device tightly with one hand and lift up the back cover at its buckle with the other hand.







- Taking out the battery: hold the side of device tightly with one hand and pull up the battery handle with the other hand.
- 4. Installing the SIM cards and Micro SD card





- a. Insert SIM cards
- The slot on the below is card 2 slot for GSM card, the upper is card 1 slot for 3G WCDMA card (compatible with EN 2



2G card).

Please make sure the gold contact area on the SIM is facing downwards.

b. Insert Micro SD card

 To insert a Micro SD card, place the card connector towards the front side of the device and the printing side of the card towards the rear side of the device.

• To remove the micro SD card, pull the card out of the slot.

5. Charging

- Insert one end of USB cable into the USB port on the device and plug the power adapter to the electrical socket.
- Normally it takes approximately 3.5 hours to fully charge the device. Operating the device while charging with the AC adapter may extend the charging time.

Notice: If you don't use your phone for a long time, it will gradually discharge. Please charge it first before your next use or charge the phone every 3 months even you don't use it.

6. Power on/Sleep Mode/Power off

- Press and hold the Power Button for a few seconds. It will automatically enter the Home screen after start-up screen.
- Press the Power Button once to enter sleep mode and press it again to awake the device.
- Press and hold the Power Button, and then tap on Power off/Standby to power off the device or to enter sleep

E۱

mode.

Technical Specifications

Processor High Performance Dual Core Cortex at 1.2 GHz

Memory 512MB RAM + 4GB eMMC, Micro SD slot supports up to 32GB

OS Android 4.1 (Jelly Bean)

Display 4.3" WVGA LCD, Capacitive multi-touch

Resolution 800*480 pixels

Band WCDMA + GSM (UMTS:900/2100MHz; GSM:850/900/1800/1900MHz)

Interfaces USB 2.0, Micro SD (micro SDHC compatible)

Communications WiFi (802.11 b/g/n), 3G

Battery 1500 mAh Li-polymer battery

Dimensions 130*67.7*10.5mm (L x W x H)

Weight 116g(without battery)



As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.



Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive1999/5/ES. Full version of the declaration of conformity is available on http://www.prestigio.com/compliance.

PAP4322 DUO EN - 5